

1.LOCATE END OF DEPRESSED CURB IN LINE WITH PROJECTED BACK OF SIDEWALK. 2.CONSTRUCT FLARES IN ACCORDANCE WITH SD-229A

## Winnipeg

## THE CITY OF WINNIPEG PUBLIC WORKS DEPARTMENT

Reference Spec. No.

CW 3240, CW 3235, CW 3310, CW 3325, CW 3326

| DIMENSIONS AND IN MILEUMETINES | DIMENSIONS | ARE | IN | MILLIMETRES |
|--------------------------------|------------|-----|----|-------------|
|--------------------------------|------------|-----|----|-------------|

| DETECTABLE           | WARNING | SURFACE | TILE |  |  |  |
|----------------------|---------|---------|------|--|--|--|
| ORIENTATION FOR      |         |         |      |  |  |  |
| OFFSET INTERSECTIONS |         |         |      |  |  |  |

| Designed By: Drawn By:         |                   | Scale :     |
|--------------------------------|-------------------|-------------|
| B.P.                           | T.G.A.            | N.T.S.      |
| Checked By:<br>B.P.            | Date:<br>12-12-15 | Drawing No. |
| Approved: SURFACE WORKS REVIEW |                   | SD-229AF    |