

## NOTES

- CONFIRM OPENING LOCATIONS BASED ON SITE CONDITIONS/INVESTIGATIONS
- 2 WOOD FRAMING TO CAN/CSA-086.1 WOOD DESIGN MANUAL & PREENG TRUSS MANUFACTURER'S RECOMMENDATIONS
- 3 WOOD FRAMING MATERIALS TO TJI STANDARD; FRAMING LUMBER NO. 2 OR BETTER
- 4 PREPARE MOCK UP OF INITIAL FLOOR OPENING FOR ENGINEERS REVIEW TO ESTABLISH STD. OF ACCEPTANCE FOR ALL FLOOR OPENINGS
- 5 RESTORE ANY AFFECTED SURFACES TO AS NEW CONDITION AND TO MATCH EXISTING
- 6 INTAKE AIR MEZZANINE FLOOR PENETRATIONS TO UTILIZE SIMILAR FRAMING DETAILS

