# 1. GENERAL

## 1.1 Shop Drawings

- .1 Submit shop drawings in accordance with Section 16010 Electrical General Requirements.
- .2 Drawings to include electrical detail of panel, branch breaker type, quantity, ampacity and enclosure dimension.

### 2. PRODUCTS

#### 2.1 Panelboards

- .1 Panelboards: product of one manufacturer.
  - .1 Install circuit breakers in panelboards before shipment.
  - .2 In addition to CSA requirements manufacturer's nameplate must show fault current that panel including breakers has been built to withstand.
- .2 Panelboards: bus and breakers rated for 250V to be 10 KA, 600V to be 14 KA (symmetrical interrupting capacity or as indicated.
- .3 Sequence phase bussing with odd numbered breakers on left and even on right, with each breaker identified by permanent number identification as to circuit number and phase.
- 4 Panelboards: mains, number of circuits, and number and size of branch circuit breakers as indicated.
- .5 Two keys for each panelboard and key panelboards alike.
- .6 Copper bus with neutral of same ampere rating as mains.
- .7 Mains: suitable for bolt-on breakers.
- .8 Trim with concealed front bolts and hinges.
- .9 Trim and door finish: baked grey enamel.

## 2.2 Breakers

- .1 Breakers: Refer to Section 16477 Moulded Case Circuit Breakers.
- .2 Breakers with thermal and magnetic tripping in panelboards except as indicated otherwise.
- .3 Main breaker: separately mounted on top or bottom of panel to suit cable entry. When mounted vertically, down position should open breaker.

# 2.3 Equipment Identification

- .1 Provide equipment identification in accordance with Section 16010 Electrical General Requirements.
- .2 Nameplate for each panelboard size 4 engraved as indicated.
- .3 Nameplate for each circuit in distribution panelboards size 2 engraved as indicated.
- .4 Complete circuit directory with typewritten legend showing location and load of each circuit.

# 2.4 Acceptable Products

- .1 Cutler Hammer
- .2 Schneider

## 3. EXECUTION

### 3.1 Installation

- .1 Locate panelboards as indicated and mount securely, plumb, true and square, to adjoining surfaces.
- .2 Mount panelboards to height specified in Section 16010 Electrical General Requirements or as indicated.
- .3 Connect loads to circuits.
- .4 Connect neutral conductors to common neutral bus with respective neutral identified.

### **END OF SECTION**