



GENERAL NOTES

1. NOT ALL COMPONENTS AND MATERIALS ARE SHOWN IN ALL DETAILS. REFER TO SPECIFICATIONS.
2. SUMP MUST BE 3/4" [19mm] TO 1/2" [13mm] LOWER THAN THE ADJACENT INSULATION. SHAVE EDGE DOWN TO PROVIDE SMOOTH TRANSITION.

KEY NOTES

1. APPLY COMPATIBLE CEMENT AT THE INTERSECTION OF THE DRAIN AND THE VAPOUR BARRIER.
2. INSTALL SPRAY FOAM INSULATION IN ALL VOIDS AROUND THE DRAIN.
3. APPLY A BEAD OF COMPATIBLE CEMENT AROUND THE PERIMETER OF THE CLAMPING RING. EMBED GRANULES.
4. EXTEND INTER PLY AND CAP SHEET INTO THE DRAIN 1" [25mm] MIN. SET IN A 1/8" [3mm] THICK BED OF COMPATIBLE CEMENT.
5. REFER TO DETAIL 1 ON A 5.01 FOR ROOF COMPOSITION.

RMIS ENGINEERING



389 MAXWELL CRESCENT
Regina, SK S4N 5X9
www.rmiseng.ca
Phone 306.352.4606
Fax 306.352.4607



LIVING PRAIRIE
MUSEUM
C.13.SK.35-18.03.03

2795 NESS AVENUE
WINNIPEG, MB R3J 3S4

CITY OF WINNIPEG

4TH FLOOR - 135 KING STREET
WINNIPEG, MB R3B 1J1

No.	DATE	DESCRIPTION

DESIGNED BY SMC 04/18/2018
DRAWN BY SED 04/18/2018
REVIEWED BY SMC 04/18/2018

DRAIN
DETAILS

A 5.04